

```
pip install scikit-image
```

```
Requirement already satisfied: scikit-image in
/usr/local/lib/python3.10/dist-packages (0.19.3)
Requirement already satisfied: numpy>=1.17.0 in
/usr/local/lib/python3.10/dist-packages (from scikit-image) (1.23.5)
Requirement already satisfied: scipy>=1.4.1 in
/usr/local/lib/python3.10/dist-packages (from scikit-image) (1.11.4)
Requirement already satisfied: networkx>=2.2 in
/usr/local/lib/python3.10/dist-packages (from scikit-image) (3.2.1)
Requirement already satisfied: pillow!=7.1.0,!=7.1.1,!=8.3.0,>=6.1.0
in /usr/local/lib/python3.10/dist-packages (from scikit-image) (9.4.0)
Requirement already satisfied: imageio>=2.4.1 in
/usr/local/lib/python3.10/dist-packages (from scikit-image) (2.31.6)
Requirement already satisfied: tifffile>=2019.7.26 in
/usr/local/lib/python3.10/dist-packages (from scikit-image)
(2024.1.30)
Requirement already satisfied: PyWavelets>=1.1.1 in
/usr/local/lib/python3.10/dist-packages (from scikit-image) (1.5.0)
Requirement already satisfied: packaging>=20.0 in
/usr/local/lib/python3.10/dist-packages (from scikit-image) (23.2)
```

```
import os
import xml.etree.ElementTree as ET
import numpy as np
import matplotlib.pyplot as plt
from skimage import io, color, exposure, filters
from sklearn.metrics.pairwise import euclidean_distances,
manhattan_distances, cosine_distances
from skimage.feature import hog
from sklearn.decomposition import PCA
from skimage.transform import resize
from skimage import img_as_ubyte

# Code Snippet 1: Function to get bounding boxes from Annotations
def get_bounding_boxes(annot):
    xml = annot
    tree = ET.parse(xml)
    root = tree.getroot()
    objects = root.findall('object')
    bbox = []
    for o in objects:
        bndbox = o.find('bndbox')
        xmin = int(bndbox.find('xmin').text)
        ymin = int(bndbox.find('ymin').text)
        xmax = int(bndbox.find('xmax').text)
        ymax = int(bndbox.find('ymax').text)
        bbox.append((xmin, ymin, xmax, ymax))
    return bbox
```

```

# Code Snippet 2: Cropping and Resizing Images
def process_images(dog_images, annotations):
    for i in range(len(dog_images)):
        bbox = get_bounding_boxes(annotations[i])
        dog = io.imread(dog_images[i])
        for j in range(len(bbox)):
            im2 = dog[bbox[j][1]:bbox[j][3], bbox[j][0]:bbox[j][2]]

            # Check if the cropped region is not empty before resizing
            if im2.size > 0:
                im2 = resize(im2, (128, 128), anti_aliasing=True)

                # Convert image to 8-bit unsigned integer format
                im2 = img_as_ubyte(im2)

                new_path = dog_images[i].replace('rajani images',
                'Cropped').replace('.jpg', f'-{j}.jpg')

                # Create the directory if it doesn't exist
                os.makedirs(os.path.dirname(new_path), exist_ok=True)

                io.imsave(new_path, im2)

# Task 2: Image Processing
def image_processing(dog_images):
    selected_images = []
    for dog_class in dog_images.keys():
        selected_images.append(dog_images[dog_class][0]) # Select
only the first image

    for img_path in selected_images:
        img = io.imread(img_path)
        gray_img = color.rgb2gray(img)
        plt.subplot(2, 2, selected_images.index(img_path) + 1)
        plt.imshow(gray_img, cmap='gray')
        plt.title('Gray Image')

    plt.show()

# Plot pixel intensity histograms
plt.figure(figsize=(10, 5))
for img_path in selected_images:
    img = io.imread(img_path)
    gray_img = color.rgb2gray(img)
    hist, bins = exposure.histogram(gray_img, nbins=256)
    plt.plot(bins, hist, label=img_path.split(os.path.sep)[-2])

plt.xlabel('Pixel Intensity')
plt.ylabel('Frequency')

```

```

plt.title('Pixel Intensity Histograms')
plt.legend()
plt.show()

# Edge detection
plt.figure(figsize=(10, 5))
for img_path in selected_images:
    img = io.imread(img_path)
    gray_img = color.rgb2gray(img)
    edges = filters.sobel(gray_img)
    plt.subplot(2, 2, selected_images.index(img_path) + 1)
    plt.imshow(edges, cmap='gray')
    plt.title('Edge Image')

plt.show()

# Edge histogram
def edge_histogram(selected_image):
    img = io.imread(selected_image)
    gray_img = color.rgb2gray(img)
    dx, dy = np.gradient(gray_img)
    angle_sobel = np.mod(np.arctan2(dy, dx), np.pi)
    hist, bins = exposure.histogram(angle_sobel, nbins=36)

    plt.subplot(1, 2, 1)
    plt.imshow(gray_img, cmap='gray')
    plt.title('Image')

    plt.subplot(1, 2, 2)
    plt.bar(bins, hist, width=np.pi / 18)
    plt.xlabel('Bins')
    plt.ylabel('Pixel Count')
    plt.title('Edge Histogram')

plt.show()

# Task 2d: Histogram Comparison
def histogram_comparison(img_path1, img_path2, img_path3):
    # Read images
    img1 = io.imread(img_path1)
    img2 = io.imread(img_path2)
    img3 = io.imread(img_path3)

    # Convert images to grayscale
    gray_img1 = color.rgb2gray(img1)
    gray_img2 = color.rgb2gray(img2)
    gray_img3 = color.rgb2gray(img3)

    # Compute histograms
    hist1, bins1 = exposure.histogram(gray_img1, nbins=256)

```

```

hist2, bins2 = exposure.histogram(gray_img2, nbins=256)
hist3, bins3 = exposure.histogram(gray_img3, nbins=256)

# Plot histograms
plt.figure(figsize=(12, 6))
plt.plot(bins1, hist1, label='Image 1')
plt.plot(bins2, hist2, label='Image 2')
plt.plot(bins3, hist3, label='Image 3')
plt.xlabel('Pixel Intensity')
plt.ylabel('Frequency')
plt.title('Histogram Comparison')
plt.legend()
plt.show()

# Task 2e: Histogram of Oriented Gradient (HOG) feature descriptor
def hog_descriptor(img_path):
    # Read the image
    img = io.imread(img_path)

    # Convert the image to grayscale
    gray_img = color.rgb2gray(img)

    # Compute HOG descriptors
    orientations = 9 # You can adjust this value based on your
requirements
    pixels_per_cell = (8, 8)
    cells_per_block = (2, 2)

    hog_features, hog_image = hog(gray_img, orientations=orientations,
                                pixels_per_cell=pixels_per_cell,
                                cells_per_block=cells_per_block,
                                block_norm='L2-Hys',
                                visualize=True, multichannel=False)

    # Plot the image and HOG descriptors
    fig, (ax1, ax2) = plt.subplots(1, 2, figsize=(12, 6), sharex=True,
sharey=True)

    ax1.imshow(gray_img, cmap=plt.cm.gray)
    ax1.set_title('Input Image')

    # Rescale histogram for better display
    hog_image_rescaled = exposure.rescale_intensity(hog_image,
in_range=(0, 10))

    ax2.imshow(hog_image_rescaled, cmap=plt.cm.gray)
    ax2.set_title('Histogram of Oriented Gradients')
    plt.show()

```

```

# Task 2f: Dimensionality reduction (using Principal Component
Analysis, PCA)
def pca_dimensionality_reduction(hist_vectors):
    if not hist_vectors:
        print("Error: Input array is empty.")
        return

    # Convert the list of histograms to a 2D array
    X = np.vstack(hist_vectors)

    # Perform PCA
    pca = PCA(n_components=2)
    reduced_data = pca.fit_transform(X)

    # Plot the 2D points using different colors for data from the 2
    classes
    plt.figure(figsize=(8, 6))
    for i, dog_class in enumerate(hist_vectors):
        plt.scatter(reduced_data[i * len(dog_class):(i + 1) *
len(dog_class), 0],
                    reduced_data[i * len(dog_class):(i + 1) *
len(dog_class), 1],
                    label=f'Dog Class {i + 1}')

    plt.xlabel('Principal Component 1')
    plt.ylabel('Principal Component 2')
    plt.title('PCA Dimensionality Reduction')
    plt.legend()
    plt.show()

dog_images = {
    'n02105412-kelpie': ['/content/drive/MyDrive/rajani
images/n02105412-kelpie/n02105412_1031.jpg', '/content/drive/MyDrive/
rajani images/n02105412-kelpie/n02105412_1078.jpg'], # List of image
paths for class 'n02105412-kelpie'
    'n02102480-Sussex_spaniel': ['/content/drive/MyDrive/rajani
images/n02102480-Sussex_spaniel/n02102480_101.jpg', '/content/drive/
MyDrive/rajani images/n02102480-Sussex_spaniel/n02102480_105.jpg'], #
List of image paths for class 'n02102480-Sussex_spaniel'
    'n02093991-Irish_terrier': ['/content/drive/MyDrive/rajani
images/n02093991-Irish_terrier/n02093991_1026.jpg', '/content/drive/
MyDrive/rajani images/n02093991-Irish_terrier/n02093991_1038.jpg'],
    'n02098413-Lhasa': ['/content/drive/MyDrive/rajani
images/n02098413-Lhasa/n02098413_10144.jpg', '/content/drive/MyDrive/
rajani images/n02098413-Lhasa/n02098413_10285.jpg'],
    # Add paths for other classes
}

# Generate histograms
hist_vectors = []


```

```

for dog_class, img_paths in dog_images.items():
    for img_path in img_paths:
        img = io.imread(img_path)
        gray_img = color.rgb2gray(img)
        hist, _ = exposure.histogram(gray_img, nbins=36)
        hist_vectors.append(hist)

# Call the pca_dimensionality_reduction function with the generated
# histograms
pca_dimensionality_reduction(hist_vectors)

```



```

# Main execution
dog_images_folder = '/content/drive/MyDrive/rajani images'
annotations_folder = '/content/drive/MyDrive/rajani annotations'

dog_images = {}
annotations = {}

# Load images and annotations
for folder_name in os.listdir(dog_images_folder):
    folder_path = os.path.join(dog_images_folder, folder_name)

```

```


    images = [os.path.join(folder_path, img) for img in
os.listdir(folder_path)]
    dog_images[folder_name] = images




for folder_name in os.listdir(annotations_folder):
    folder_path = os.path.join(annotations_folder, folder_name)
    annotations[folder_name] = [os.path.join(folder_path, annot) for
annot in os.listdir(folder_path)]

# Task 1: Cropping and Resize Images
process_images(dog_images['n02105412-kelpie'], annotations['n02105412-
kelpie'])


# Task 2: Image Processing
image_processing(dog_images)

```






```
# Task 2c: Edge histogram
selected_image = dog_images['n02105412-kelpie'][0] # Select one image
for edge_histogram
edge_histogram(selected_image)
```


```
# Task 2d: Histogram Comparison
```

```
histogram_comparison(dog_images['n02105412-kelpie'][0],  
dog_images['n02105412-kelpie'][1], dog_images['n02098413-Lhasa'][0])
```



```
# Task 2e: Histogram of Oriented Gradient (HOG) feature descriptor
hog_descriptor(dog_images['n02105412-kelpie'][0])
```

```
<ipython-input-82-85579771c006>:14: FutureWarning: `multichannel` is a
deprecated argument name for `hog`. It will be removed in version 1.0.
Please use `channel_axis` instead.
hog_features, hog_image = hog(gray_img, orientations=orientations,
```



```
# Print the keys in dog_images dictionary
print("Keys in dog_images:", dog_images.keys())
```

```
Keys in dog_images: dict_keys(['n02105412-kelpie', 'n02102480-
Sussex_spaniel', 'n02093991-Irish_terrier', 'n02098413-Lhasa'])
```

```

# Task 2f: Dimensionality reduction (using Principal Component
Analysis, PCA)
hist_vectors = []

# Replace '...' with the actual paths to images for each class
for img_path in dog_images['n02105412-kelpie'][:2] +
dog_images['n02093991-Irish_terrier'][:2]:
    img = io.imread(img_path)
    gray_img = color.rgb2gray(img)
    hist, _ = exposure.histogram(gray_img, nbins=36)
    hist_vectors.append(hist)

pca_dimensionality_reduction(hist_vectors)

```

